



DWL66⁺

*Doc. No.: DWL-HI-023
Revision: 5a (Jan. 2014)*

Copyright © 2014 by Heidelberg Instruments

Table of Contents

Preface	1
Precautions and Safety, Terminology	1
Conventions Used	1
Related Documentation.....	2
Contact.....	3
Chapter 1: Startup and General	5
Tutorial: Basic Setup	5
Recommended Setup	10
User Permissions Management	12
Managing Users	12
Adapting User Permissions	13
General Functions.....	16
Wizards	16
Panels	19
Main Menu	19
Lists.....	19
Chapter 2: File, Window, Help	21
Chapter 3: Controls	22
Metrology → Cameras	23
Toolstrips.....	23
Control.....	24
Keys	24
Calibration	25
Metrology → Measurement Recipes	25
Toolstrips.....	25
Grid	26
Measurement	27
Evaluation	32
Test	32

Metrology → Measurements	33
Toolstrips.....	33
Metrology → Templates	34
Toolstrips.....	34
Exposure → Designs	35
Toolstrip	35
DWL66SystemController View Panel – Functions.....	35
DWL66SystemController View Panel – Properties.....	35
Scripts.....	37
Job	38
Toolstrips.....	38
Browser section.....	40
Editing/Execution Section - Editing Containers	40
Editing/Execution Section - Editing Jobs / Job Templates.....	42
System Control	55
Stage function set.....	55
Writehead function set.....	56
Show Options.....	56
Toolstrip Items – Commands.....	57
Chapter 4: Wizardry	61
Chapter 5: Tools.....	63
FireFips Configuration.....	65
Menu configuration	66
Edit menu configuration panel.....	66
Edit System menu configuration panel.....	66
DebugLevelEditor	67
Chapter 6: Devices.....	68
Common Toolbars	68
Properties.....	68
Log	69

Connect.....	69
Communication log section.....	70
Tabs	70
Functions.....	70
Appendix A: Glossary	71
Appendix B: Revision History	73

Preface

This manual is a reference guide for the **Lithography Menu**, providing information for every feature included. The first chapter contains some general information related to the setup of the menu. The following chapters are sorted by menus, and sections are defined by the functions in those menus, including functions that depend on system configuration options. Each function is described in its functionality as well as in the context of possible applications.

Step-by-step instructions on how to use the common functions of the **Lithography Menu** in the context of standard system operation are given in **User Guide I: System Operation**.

In the appendix, a menu revision history with information on later additions and bugfixes can be found.

Precautions and Safety, Terminology

The DWL 66FS uses lasers and high voltage electronics. It is therefore vital that the operators and all other persons who are allowed access to the system have been informed about the safety risks stated in this manual and **User Guide Part I: System Operation**.

No untrained person, or person not familiar with the contents of all related safety sections may be allowed to operate the system or work in its close environment. If instructions are not followed carefully, danger to personal health and damaging the equipment is at risk.

CONVENTIONS USED

Throughout this manual there are safety warnings.

To classify the degree of danger in each of these situations, this guide uses the conventions defined in ANSI Z535.6-2011:

	Fatal or severe injuries can occur if instructions are not followed.
	(Severe) injuries can occur if instructions are not followed.
	Mild injuries are possible if instructions are not followed.
	Denotes advice to avoid machine damage, as well as hints for a more effective use of the machine.

For more details on safety risks refer to **User Guide I: System Operation**.

Additional terminology conventions used in this manual are:

Note: Gives advice or hints to help the user to find the best solutions for the task at hand

Also, in some parts of this user manual, general information is given including special symbols that are used as wildcards. These wildcards stand for entries that change with each specific instance of application. The wildcards used in this manual are:

<....> - text between angular brackets denotes which information is expected here. The brackets are part of the wildcard and don't occur in the final text.

Related Documentation

Heidelberg Instruments offers several further manuals related to the machine and its operation. If you did not get one of these or need an update, please contact Heidelberg Instruments, Germany.

Pre-Installation Guide

System requirements, sizes and weights of components etc.

Safety Guide

Describes risks and safety measures during installation and service periods

Conversion Software Manual

Manual for the HIMT conversion software used for data preparation and fractioning

User Guide, Part I

Step by step instructions for general system usage and standard applications

Contact

Should you need assistance, please call Heidelberg Instruments during normal business hours (CET)

Phone: +49-6221-3430-0
Fax: +49-6221-3430-30

or contact your local service office:

China:

Heidelberg Instruments China
Rm.101, Block 1, Animation Park,
Yuehai Street, Nanhai Road,
Nanshan Distr., Shenzhen 518045
China
Phone: +86-755-8301599-1 / -2 / -7
Fax: +86-755-8301599-4
email: service_china@himt.de

Japan:

Heidelberg Instruments Japan
Germany Center for Industry & Trade
1-18-2, Hakusan
Midori-ku, Yokohama, 226-0006
Japan
Phone +81-45-938-5250
Fax +81-45-938-5251
email: service_japan@himt.de

Taiwan:

Heidelberg Instruments Taiwan
5F, No. 174 Chung Yang Road,
Hsinchu City
Taiwan
Phone: +886-35311-304/-284
Fax: +886-35311-243
email: service_taiwan@himt.de

USA:

Heidelberg Instruments Inc. USA
2807 Oregon Court, Unit E2
Torrance, CA, 90503
USA
Phone: +1-310-212-5071
Fax: +1-310-212-5254
email: service_usa@himt.de

Korea:

Heidelberg Instruments Korea
#316 Expo Officetel, 381
Mannyeon-dong, Seo-gu
Deajeon 302-834
South Korea
Phone: +82-42-482-1668
Fax: +82-42-482-1669
email: service_korea@himt.de

You can also reach Heidelberg Instruments via e-mail: himt@himt.de, or visit our site on the Internet: <http://www.himt.de>

Chapter 1: Startup and General

The **Lithography Menu** usually comes with pre-configured standard users that are equipped with certain typical permissions for the tasks they have to perform. The typical functionalities have been arranged in an intuitive way to help operating the machine without having to continuously open and close windows or panels.

For new users, default setups exist that match the typical tasks of the related user level. These can be adjusted in any useful way to adapt the menu to the daily operations of this user. As these setups are different for each user level, for the tutorial, we start with an empty menu.

Tutorial: Basic Setup

The fresh interface consists of the menu bar, two anchored containers and a floating container. At the bottom, a status bar shows the name and user level of the currently logged in person on the left, and some status information on the machine on the right.



The **LiveWindow** shows all messages from the program. It depends on the menu settings if it stays open after startup.

For the moment, the floating container should be either moved to the other window by drag-and-drop, or closed. To close the container, click on the cross button in the upper right corner and select **Close floating window**. It can be opened again anytime from the menu **Tools** by selecting **Floating window**.

Maximize the main window of the **Lithography Menu**.


The size of the anchored containers can be changed by grabbing the divisor by right-click on it and moving it while the mouse button is held down:



The containers are used to deposit frequently used windows (control panels, wizards, log windows) in them, so that whenever the user logs in again these are automatically started in the same configuration they were last in.


As an example, we open the **Designs** panel (Menu **Controls** → **Designs**). The panel opens in a random position and floats freely. We can either leave it like that and keep pushing it around whenever it is in the way, or dock it into one of the containers.

When grabbing the panel with the mouse, as soon as we start moving it around, a representation of possible docking positions within the container appears:



Each arrow stands for one of the borders of the container, while the center button arranges the panel as a new register card behind the panel(s) that is/are currently docked into this container.


Keep holding down the mouse button and move the mouse cursor onto the icon for the position in which the panel should be docked:




Now release the button.

As only one window is open yet, it makes no difference which arrow was chosen; the panel will fill the complete container. Only if the register card was chosen a difference can be seen: Instead of the usual window top bar, the panel gets a register tab with the cross button for closing.


To see the effects of arrangement within the container, open a second window. The only other window available even in the most basic setting is the **Memos** window (**Tools** → **Memos**). Again, it appears first as a floating window:




Drag-and-drop it like the previous one to one of the border arrows, e.g. the right one. The previous window will automatically be resized to make room for this second window that is now docked into the container:



Each window can be made to float again by grabbing it at the top bar and dragging it away. Remove the Memo window from the container in this way and dock it in again as register card, using the center icon of the docking cross:



Now, each window fills the container completely, and the tabs can be used to swap between the windows. Grabbing the tab and pulling it away again removes the window from the container and returns it to floating state. Dock it into the second container for practice:



Note that the remaining window is still a register card, even though it is the only one left in this container.

Floating windows may slip behind the main window if something is selected there. In such a case, the window can be brought back to the front using the **Window** menu. Try that by removing the **Memo** window from the second docking container again and clicking anywhere in the main window afterwards. The floating window slips behind. Bring it to the front again.

Floating windows can be positioned outside the main window of the Lithography Menu. However, floating windows generally are not restored when the menu is restarted. If a window should generally be positioned outside the main window, or should stay floating, but still be restored at startup, it has to be docked into the **Floating Container**.

The **Floating Container** opens at first menu start. If it was closed after that, it can be re-opened at any time from the **Tools** menu by just selecting **Floating Window**. Dock the floating window into the **Floating Container**, and position that wherever you want it. Now, this window is available even after a restart of the menu. Also, the **Floating Container** always stays on top of the **Lithography Menu**.

Undock and close the windows used for testing and start creating your own setup according to the available functions and what you require regularly in the current login.

Recommended Setup

User Permissions Management

The **Lithography Menu** offers five user groups in a hierarchic structure:

1. Administrator (all permissions available from start)
2. HIMT engineer
3. Custom administrator
4. Custom engineer
5. Custom operator

It also offers a host of permissions that determine which functions are visible for a certain user, or what he can modify. Permissions are sorted into groups that can be assigned to each user according to the needs of his work.

To access the user database in the **Manage user database** panel, open **Tools → User manager**.

In the top level, there is an alphabetical list of all users whose settings can be modified by the current user, plus the current user himself. After each login name, the user group to which the corresponding user belongs is written in brackets. Clicking on the plus (+) sign close to a user name shows the permissions this user has been granted so far. The right half of the window contains a list of all available permissions, sorted in categories. The permissions granted to the currently selected user have a tagged checkbox.

NOTICE:

User management permission should be granted rarely, as it can strongly influence the versatility of the system for the users! Only few administrators should have this permission.

MANAGING USERS

Users can be added or deleted using the controls of the **User** toolstrip.

- **Adding users:**

1. Click on the plus (+) sign. A dialog window opens
2. Enter name and password of the new user
3. From the drop-down list, select the user group that the user should belong to

- **Deleting users:**

1. Highlight the user to be deleted
2. Click on the plus (-) sign
3. Confirm

In addition, there is a control **Change password** in the **User** toolstrip. It allows to change the password of any of the listed users to a new password specified by the administrator.

ADAPTING USER PERMISSIONS

For user permissions management, the following rules apply:

- Each user can only create users belonging to his own group or a group below that.
- In the same way, users can only modify the permissions of other users in the same or a lower group.
- Each user can only hand on permissions he himself possesses.
- Users can not change their own permissions.

Only administrators have all available permissions from the start. Which of these are handed down to users of other groups is defined by the administrators during creation of the new users.

Only names of users whose permissions can be modified appear in the list of users. The own name appears in red, as no user can modify his own permissions.

Permissions can be granted or withdrawn by marking a user and then ticking/unticking the checkboxes in the list on the right. Also, permissions can be withdrawn by opening the permission list of a user (plus (+) sign beside the name), highlighting the permission and clicking on the minus (-) button in the **Permissions** toolstrip.

For a list of all available user permissions groups and their effects see the table below. In the following sections, each feature of the **Lithography Menu** is marked with the user permissions group required to use it.

User Permission Item	User Permission Group	Menu Item(s)	Other Item(s)
None required	None required	File→* Wizardry Tools→Floating window Tools→Change password Tools→DebugLevelEditor Window Help→*	Floating container Help functions DebugLevelEditor
Category Menu			
Control.Access.	AllControls	Controls→*	all control panels, overrides single selection
	AllWizards	Wizardry→*	all wizards, overrides single selection
Menu.	AccessAllDevices	Device→*	all device control panels
	ChangeLanguage	Tools→Language→*	
	AccessLogService	Tools→LogService→*	LiveWindow
	AccessFireFips	Tools→FireFips→*	Edit FireFips configuration panel Show communication window
Menu.	AccessConfiguration	Tools→Configuration→Menu	Edit menu configuration panel

User Permission Item	User Permission Group	Menu Item(s)	Other Item(s)
Device.	Initialize	Devices→*	All device windows: Initialize device
	AccessSpecificArea	Devices→*	All device windows with specific data sets available: Update view → Set up view
	AccessDummyMode	Devices→*	All device windows: Activate/Deactivate dummy mode
	AccessConfiguration	Devices→*	All device windows: Edit configuration
	AccessLog	Devices→*	All device windows: Show/hide log viewer Save log
Writemode.	Change		Main Menu: Write mode selection control
	Modify		Main Menu: Create write mode control Delete write mode control Edit write mode control
Database.	Administration	Tools→User manager	Manage user database window Permissions list filled with own permissions
Job.	Modify		Job control panel: Activate die Deactivate die Columns Create series Fit map control to container Clear designs Templates list Editing register card
	ModifyTemplates		Job control panel: Create template Remove template
Category Wizards			
Wizard.Access	BeamOffsetCalibration Wizard	Wizardry→Writehead→Calibrate beam offset	Beam offset calibration wizard
	CameraOffsetCalibrationWizard	Wizardry→Camera→Set camera offset	Camera offset wizard

User Permission Item	User Permission Group	Menu Item(s)	Other Item(s)
Wizard.Access	BacksideCameraOffsetCalibrationWizard	Wizardry→Camera→Set camera offset	Camera offset wizard
	CameraCalibrationWizard	Wizardry→Camera→Calibrate camera	Camera calibration wizard
	GlobalAlignmentWizard	Wizardry→Alignment→Global alignment	Global alignment wizard
	AlignmentScriptCreationWizard	Wizardry→Alignment→Create alignment script	Alignment script creation wizard
	ExposureItemWizard	Wizardry→Job management→Create/execute exposure job	Job creation/execution wizard
Category Controls			
Control.Access.			
	DesignsWizard	Controls→Designs	Designs list panel
	MeasurementRecipesWizard	Controls→MeasurementRecipes	Measurement recipe setup panel
	Measurements Wizard	Controls→Measurements	Measurement algorithm creation panel
	MemoWizard	Controls→Memo	Memo editor
	ScriptWizard	Controls→Scripts	Script creation panel
	TemplateWizard	Controls→Templates	Video template creation panel
	ProcessWizard	Controls→Job	Job control panel: Control Execute Stop Job list Execution status register card
	SystemControl Wizard	Controls→System control	System control panel
Category Devices			
Device.Access.	<device name>	Devices→<device name>	Device window of <device name>, available controls depend on general settings
	Cameras	Devices→Camera Selector→Camera	Camera control panel




Figure 1: User database


General Functions

The **Lithography Menu** mainly consists of wizards that lead through certain typical procedures step by step, and panels, that group together controls related to a certain task. Apart from the specific functions of each wizard or panel, there are some functions that are common to all menu components of one type. These, and the menus from which all functions can be accessed, are explained here.

Also, there are certain features that appear in several contexts. How these are used is also part of this section.

WIZARDS

Step numbers: In each sequential wizard, numbers on the left represent the steps of the sequence. Steps that may be selected are colored, inactive steps appear in greyscale. The current step is marked by a frame.



Usually, a step gets activated once the previous step has been finished. However, sometimes steps are skipped and stay inactive because of a selection that was done, or several steps are activated at the same time, so steps can be omitted by the user. This can speed up the sequence if default values are to be used.

Also, by clicking on the number of a step, it is possible to return to that point and check on or change the selection done there.

QuickMode:



At the bottom of each wizard, the Quick Mode can be turned on or off with a button showing the icon of a green running man.




Figure 2: A wizard panel with description window open and pinned

When in Quick Mode, whenever there is a step that consists only of a selection between options, the wizard automatically jumps to the next step as soon as this selection is done.

Description: The Description control opens a text field with a description of the task at hand in the current step.

If the text field is opened by just hovering with the mouse pointer over the control, it closes again immediately when the mouse pointer is moved outside the area of control and text field. The title bar of the field is light grey in this mode.

If the field is opened by clicking on the control, it stays open until the user has clicked into some other region of the menu window. The title bar of the field is dark grey in this mode.

A pin is visible at the right end of the title bar in both cases. A click on this pin fixes the text field so that it stays open even if the mouse is moved out of the area / a mouse click occurs outside the area. All controls that were previously covered by the field are shifted above it, and its height can be changed by click-and-drag on the border. In this way, the description can be kept open through all steps.

The pin is removed by another click, returning the text field to the previous property.

Edit settings A toolbox icon button at the bottom of each wizard opens the **Edit wizard settings** window for that wizard. Here, the user can select if the descriptions for each step should be shown in a pinned window at the bottom of the wizard per default, or not. The description window can always be opened and pinned manually.


Restart With the double arrow button at the bottom, the wizard is restarted. Previous values are kept in the edit boxes for reuse. This function is important if a wizard is docked in and kept open continuously. If a wizard is closed after each use, it is automatically restarted at the next call.

Navigation arrows

At the bottom of each wizard, there are arrows for navigation. These can be used to navigate between active steps. Which steps are active can be seen from the number list (see above). The first button serves to directly jump back to the first step, the others move just one active step back or forward.

PANELS

toolstrips:



Toolstrips contain controls that are either marked by icon buttons, or by text. Depending on the orientation, each toolstrip has a name written in orange at either the left (horizontal) or the top (vertical).

Toolstrips can be moved along the panel borders by drag-and-drop if grabbed at the dotted line at the left/top end. The toolstrip changes orientation automatically to align to the closest border. All other controls shift to make room for toolstrips along a border once one toolstrip is positioned there.



If a toolstrip is too long for a certain position, the controls that do not fit into the available space are hidden and can be accessed via a small arrow at the toolstrip end.


Show options:



In the **Main** toolstrip, a toolbox icon button offers access to general settings of a panel. In the left half of the settings window, general settings like colors or units can be adapted for that panel. The right half contains the toolstrip manager. As adaption of the toolstrips will usually only take place in the **System control panel (Controls → System)**, this feature is explained there.

MAIN MENU

The **Main menu** of the **Lithography Menu** is the starting point of all operations. From here, wizards and control panels can be opened, and certain functions can be started. It is the only menu in the graphical user interface, as all panels use toolstrips to sort functions.




Features of the menu:

- entries with arrows open submenus with further options
- plain entries can either be direct controls, or they open panels or wizards
- checkmarks in blue fields mean that either the wizard/panel related to the entry is already open, or the option/function that can be selected/started is already active.

LISTS

Among other items, panels and wizards may contain folder lists or grids with parameters. To help to get a quick overview, all contents are not always visible at once.

- Working with folder lists:



Folders can only be opened or closed by clicking on the plus (+) or minus (-) signs attached to them. In some places, clicks on folders open properties windows for the whole folder and all its contents.


An orange warning triangle means that an item is missing data.

A cross to the left of an icon means that the item is selected.

A right-click on browser items opens a context menu with functions related to this item.

During execution of an item, a double-arrow appears next to it.

- Extending / collapsing parameter lists:



Main groups are usually extended by default. Subgroups that can also be displayed as one parameter are collapsed. Control over extended or collapsed view is given by the small triangles:

▲ filled triangle: parameters below up to the next heading belong to a group that may be collapsed to have a better overview.

▶ empty triangle: a sub-group of parameters exists and may be accessed by clicking on the triangle.

- Changing parameters in parameter lists:

Generally, all parameter lists are tables with the parameter or parameter group names in the left column and an editable field in the right column at each parameter. Some fields can be edited directly (text fields), for some, only certain options are available that are offered in a drop down list, or a separate window is required to make a selection.

- 1) For **direct editing**, just click into the field. A cursor appears, and the contents can be edited.
- On ▼ If a **drop down list** exists, the click makes an arrow appear. Click on the arrow to open the list. Click on a list item to select it. It is transferred to the text field, and the list closes.
- (none) ... If a **separate window** is required for the selection (e.g., for selection of a file), a button with three points appears at the right side of the text field. This button opens the required window. As soon as that window is closed again, the result of the operation(s) done there is transferred to the text field.

Chapter 2: File, Window, Help

These three menus contain the most general functions of the **Lithography Menu**.

- **File**

Close – closes the **Lithography Menu**, ending all currently running tasks. All settings except those of floating windows are saved so that at the next menu start, the interface looks the same as before.

- **Window**

Lists all windows and panels that are currently open. Clicking on an entry in this list brings the related window or panel to the foreground.

Note: The **HIVision** window is not part of the **Lithography Menu** and therefore not listed here. See above for more information on **HIVision**.

- **Help (Note: no content available as of V 1.0, please check Revision history for changes)**

Content – gives access to a table of contents of the available online documentation

Index – gives access to a list of indexed keywords provided in the online documentation

Search – opens a search panel to search for a certain keyword or phrase within the online documentation contents

About – opens a window with **Lithography Menu** version information

Chapter 3: Controls

In the **Controls** menu, all control panels are collected that support the operator in certain tasks like the manual setup and execution of jobs, the definition of camera templates or the direct control of hardware components.

Functions require user permissions of the Control.Access.<group name> category, or user permission group Control.Access.AllControls.

- Metrology** – This is a group of controls that all relate to measurements.
- Measurement recipes** – panel for creation and administration of measurement sequences based on a camera image
Requires user permission group MeasurementRecipeWizard
 - Measurements** – gives direct access to the optical measurement methods available in the sequences as well as mechanical methods, for single measurements
Requires user permission group MeasurementsWizard
 - Templates** – panel for definition and administration of camera image templates
Requires user permission group TemplatesWizard
- Exposure** – This is a group prepared for controls related to exposures.
- Designs** – panel for viewing and management of designs available on the defined data sources
Requires user permission group DesignsWizard
- Memo** – Opens a simple editor to make and save notes.
Requires user permission group MemoWizard
- Scripts** – Opens a panel for scripts management and programming
Requires user permission group ScriptsWizard
- Job** – This is one of the central control panels. It contains all necessary controls for definition and execution of jobs, exposures as well as measurements.
Requires user permission group ProcessWizard
- SystemControl** – This is another key control panel, as it gives access to manual control of several components.
Requires user permission group SystemControlWizard
-

Metrology → Cameras

This panel offers control functions for everything related to the camera image. While the general functions are collected in toolstrips, specific controls are sorted in three control sets: **Control**, **Keys** and **Calibration**.

TOOLSTRIPS

Main

see *Chapter 1: Startup and General*, section *General Functions*

ImageControl


contains icon buttons for start and stop of image acquisition, as well as a text control for **Snapshots** and text controls for camera selection (MacroCamera, MicroCamera ...)




'Live', restarts image after it was frozen e.g., for a measurement or a snapshot



'Snap', stops image acquisition and holds last image



freezes the image and offers to save it as an image file



camera selection controls, the blue frame denotes the currently active camera

SystemSetup

contains controls related to the **Keys** control set



- adds a new system setup key



- deletes the currently highlighted system setup key



- applies the highlighted system setup key

CONTROL

This control set contains sliders for adjustment of parameters that influence the current camera image. . Controls at both ends of each slider allow to jump directly to the limit values. Above each slider, the current value is shown.

Position (-100 – 100) motorized cameras only (configuration dependent). Controls the position of the camera

Brightness (0 – 100%) regulates the power of the illumination light source.

Offset (-100 - 100) controls the minimum amount of light necessary to create a gray level for a pixel. This function can reduce the stray light influence, or elevate the light level from substrates with very low reflectivity to visibility. Beside the current value, a control allows to reset the offset to **0**.

Exposure Time (0 – 100 seconds) determines the time span of light acquisition for each image. Should be used if the **Brightness** range is not enough to give a satisfactory result.

Gain (0 – 30) increases the contrast by multiplication of each pixel value with a certain factor. As also the base light level is increased in this way, usually this has to be used in combination with the **Offset** regulation to get a satisfactory contrast

KEYS

The **Keys** control set serves to manage parameter sets for camera images (keys). They can be used to save parameter sets that are used often, in case that on the one hand different kinds of substrates with different reflectivity are used, but on the other hand every type comes into use often enough to need a fast way of switching to the related camera settings. These keys can be used wherever measurements are done (alignment scripts, measurement scripts, and the related panels).

The left part of the keys control set shows a list of existing keys for the currently selected camera. The parameters contained in the highlighted key are listed in the right half of the window and can be edited there. These are:

CameraParameterSet same as **Exposure Time**, **Gain** and **Offset** above

FocusOffset offset of the write lens with respect to the default position where the camera image is sharpest

LampParameterSet same as **Brightness** above

PositionOffset offset of the camera position with respect to the default position in systems with motorized cameras

Controls for adding or deleting complete keys are available in the **SystemSetUp** tool strip and explained above.

CALIBRATION

The **Calibration** control set is actually only a list of information on calibration data related to the currently selected camera. The data can only be changed via the related calibration wizards (**Wizards** → **Calibration**), or via the **Device** panel of that camera (user permissions required for access).

The parameters on calibration are:

Date	Date when the last calibration operation was done
Matrix → Camera2World	A matrix representation of the camera calibration parameters
Parameters →	
Angle of rotation	Rotation of the camera with respect tot the movement axes of the stage; calculated during camera calibration
Offset X/Y	Distance between the image center of this camera and the image center of the reference camera (usually, top micro camera)
Scaling X/Y	Size of one image pixel on the substrate
BeamOffset	Distance of the begin of the writing scan from the center of the image

Metrology → ***Measurement Recipes***

This control set combines all necessary functions for setup and administration of automized measurement sequences. Also, single measurement can be done from here. The setup and test of a measurement sequence is explained in a tutorial section in the chapter on measurements in ***User Guide I***.

In the standard setup, the **MeasurementRecipes** control panel contains one specialized toolstrip, one tree view of available recipes and their sorting folders, and a variable panel with four different control sets (Grid / Measurement / Evaluation / Test) that contain the parameters defining a measurement recipe and functions for testing it (only visible if a recipe is selected). At the top of the control sets partition, the name of the currently selected recipe is shown in the **Editing:** line.

TOOLSTRIPS

Main see **Chapter 1: Startup and General**, section **General Functions**

Edit contains controls for administration of recipes



- adds a new recipe in the highlighted folder, or the general folder, if no folder is highlighted. Choose the type of measurement sequence from the drop-down list (only one type available at the moment)



- deletes the currently highlighted recipe



- creates a new folder for sorting of recipes in the highlighted folder, or the top layer if no folder is highlighted (hit ESC key to remove all selections)



- deletes the currently highlighted folder. If the folder is not empty, a warning is issued



- creates a copy of the highlighted recipe so it can be modified e.g., for measurements in the same grid but with a different measurement method

GRID

Contains the parameter set for selection of the geometrical arrangement of measurements. Some functions are available that allow to use a sample plate for easier setup of the grid.

List:

General → **Order** Defines the order in which the measurements are done. The measurement sequence can be executed line-by-line (XY), or column-by-column (YX)

Starting Point →

Offset Defines the position of the first measurement point in the grid. This has to be a corner of the measurement field. Which corner should be chosen depends only on the selection of the sign in the step definition. Values can be edited directly in this field, or in the separate fields of the appended list

Unit Unit for offset coordinates

X / Y Values of offset coordinates, to be entered in the unit selected above (same unit for both axes)

X/Y-Step → These parameters define how the grid extends from the point defined before as starting point

Count Number of measurements per row (x) / column (y)

Step → Distance between measurement points (step width). Values can be edited directly in this field, or in the separate fields of the appended list

Unit Unit for step width definition

Value Value of step width in this axis

Die center coordinate controls:

These controls serve to define the position relative to which the starting point is defined (coordinate origin for grid positioning). Usually, this is the center of the plate, or the center of a die within which measurements are to be done.

- from stage** takes the current stage position as reference position
- from camera** requests to point to the reference position in the camera image. After clicking on the button, switch to the camera image and mark the position as described in the section on the HIVision program (point of interest). The coordinates of the marked point are transferred to the list
- Zero** sets the **Die center coordinates** back to zero (0/0)

Grid definition controls:

- Re** Resets the values that are related to the neighbouring control to minimum
- Set starting point** Starts a sequence to mark the starting point in the camera image. After clicking on the button, switch to the camera image and mark the position as point of interest as described in the section on the HIVision program. The coordinates of the selected point are transferred to the list
- To** Moves to the Offset coordinates in the list
- Set x/y-step** Starts a measurement sequence to determine the step size directly from the image of a sample plate. One of the other measurement points has to be moved into view before the functions is started. After clicking on the button, switch to the camera image and mark the measurement point position. When requested for the **Index of position**, enter the index number within the row/column. The step size is calculated from that in the following way: $\text{step size} = \text{distance from offset point} / (\text{index} - 1)$
When requested for the **Total number of positions**, enter the number of measurements to be done per row/column

MEASUREMENT

This panel contains all controls necessary to define the measurement that should be done at each of the positions defined in the grid. It contains a drop-down list for selection of the measurement type, and a parameter list. Which parameters appear in the list depends on the selected measurement method.

Measurement methods list

- SingleEdgeDetectionMeasurement** Makes a single measurement detecting the position of the first edge from left / top within the area of interest (Aoi)

CenterDetectionMeasurement	Detects the positions of the first and second edge within the Aol and returns the position between them, assuming this is the center of a line
TemplatePositionMeasurement	Compares the camera image with a pre-defined template image and looks for the first match from top left that has a certain minimum degree of resemblance under coarse resolution. If comparisons with increasing resolution stay below the definedlimit, the match is dismissed and an error returned
LineWidthMeasurement	Detects the positions of the first and second edge within the Aol and calculates the distance between them
LineEdgeDetectionMeasurement	Returns the positions of the first and second edge within the Aol
ManualPositionMeasurement	Activates a point of interest measurement in the HIVision program, allowing for a manual selection of a point within the image. The coordinates of that point are returned as result
StitchingMeasurement	A measurement method that combines two CenterDetectionMeasurements to compare the distance between two lines on different sides of a stripe connection that are supposed to be at a certain distance (x-stitching) / at the same height (y-stitching)
CrossPositionMeasurement	Measures the positions of the four arms of a cross at the Aol borders
EdgeRoughnessMeasurement	Measures the position of an edge over a certain length. From the standard deviation in edge position, the edge roughness is calculated
ManualDistanceMeasurement	Starts a sequence where first a point of interest in the current image can be selected, next a movement can be done, and lastly, a second point of interest has to be marked. The distance between the two points is returned

Measurement method properties – required parameters

While the checkbox **Show only required parameters** is selected, only those parameters that always have to be adjusted to a measurement are shown. Advanced parameters that influence the details of a measurement are hidden and will only show up if the checkbox is deselected.

Devices →

Camera Selection of camera to be used for the measurement. Available cameras can be selected from the drop down list

SystemSetupKey

Selection of setup key with camera and illumination parameters to be used for the measurement. Available parameter sets can be selected from the drop down list. Nearly all measurement methods listed above are based on the detection of borders between exposed and unexposed regions. A setup with good contrast is required so these borders can be clearly detected

Image processing →**AreaOfInterest**

Defines the area within an image inside which the object should be detected. Detection always starts from left to right, and top to bottom within the selected area. Therefore, it is important that no other features are above / left of the feature that should be measured when the area of interest for the measurement is defined. Select the parameter and click on the three points at the end of the row to define the Aol directly in the image. Parameters are shown as set in the main line, and separately in the sub rows. They can be modified manually in both places

Height Height in pixels of the Aol

Width Width in pixels of the Aol

X/Y Position of the left/upper border of the Aol

Direction Axis direction for the measurement, select from the drop down list

Template Template file to be used during template detection, select from drop down list of available files

Boxes →

Count In edge roughness measurement, number of measurement points along the edge

Measurement method properties – extended parameters

Each measurement method contains some additional parameters that influence the way the measurement is done on a more advanced level.

AOIs → Sub AOI dimension

Size in pixels of the sub Aois created along the line edge within the Aoi.
Maximum size is the Aoi size in this axis divided by the number of points
(Boxes → Count)

Image processing →**Allowed center deviation**

Allowed deviation of the found position from the image center to directly accept the measurement. If the structure is found further away, the stage is moved to bring it closer to the center, and the measurement is repeated

DetectionOptions

Per factory default, the size of a line is determined from the inside of the line. The point where 50% of the difference in intensity is reached is taken as the edge position. To avoid effects of noise, an interpolation between several pixels is done. However, this is not necessarily the correct or the best way of measuring.

Especially for measurements on emulsion, great care has to be taken when setting up the parameters, as in top lighting emulsion lines tend to have more opacity in the borders than in the center. Thus, if the limits are not set properly, the image processing software might identify one thick line as a pair of thin lines instead. Similar problems might occur in thick resists, or on substrates with multiple layers.

Interpolation Number of pixels combined for averaging when calculating the relative signal level. Factory default setting **5**

Model Defines which part of the edge line curve defines the edge position (boundary **Inside** / **Outside** structure). The structure is defined to be located after the first edge detected. Factory default setting **Inside**

Threshold Signal level in % of the full signal difference that defines the position of an edge. Factory default setting **50**

Height [%]

Height of the cross arms detection area in % of the full image

ImageProcessor

If several image processor programs are available, the selection from the drop down list decides which one to use for the measurement.

Length [%]

Length of the cross arms detection area in % of the full image

NominalValue

A value that should be subtracted from the measurement values to directly get the errors or instabilities. Parameters are shown as set in the main line, and separately in the sub rows. They can be modified manually in both places

Unit Distance unit

Value Nominal distance in the given unit

Repetitions

Determines the number of detection repetitions that are averaged for the end result

StepAway

Selects if the stage moves between detection repetitions

StepAwayDelay

Sets a delay between step and new measurement. Parameters are shown as set in the main line, and separately in the sub rows. They can be modified manually in both places

Unit Time unit

Value Number of time units the delay should take

StepAwayVector

Sets movement vector for step away function. Parameters are shown as set in the main line, and separately in the sub rows. They can be modified manually in both places

Unit Distance unit

X/Y Step distance in the given unit

Threshold

Detection reliability required to accept a result

Result Accuracy →**SignificantDecimals**

Determines with how many valid decimal places the results are processed

Unit Measuring unit used in the report

Misc → LastDuration (Read only)

Duration of the last measurement done with this measurement method

EVALUATION

- Summary** If summary is enabled, the results that are averaged are listed in a summary table at the end of the report.
- Averaging** This drop down list allows to enable or disable a global averaging over all results of a grid measurement.
- Averaging Mode** If global averaging is enabled, this second list determines in which way it is executed:
- Values** All measurements from all grid points are averaged
 - MeanValues** The mean values from repetitions at one grid point are used as basis for the averaging

TEST

Functions:

Execute Starts a test measurement run

Stop Stops the test run

+ / - Opens/closes the list of parameters that describe the environment for the test execution. For more information on the parameters in this list see subsection **Properties** in the section **Job** that describes the **Job** control panel further down in this chapter

Metrology → Measurements

The **Measurements** control panel can be used to make single measurements, or create predefined parameter sets for measurements. This includes not only the structure measurement methods known from the **Measurement Recipes** control panel, but also algorithms used in global alignment or during calibrations.

In general, this panel is quite complex to use for single measurements. It is therefore recommended to rather use the **Measurement Recipes** control panel described above with just one grid point defined, or to create a toolbar item from the Measurements set in the **System Control** panel.

The two functions of this panel reflect in the two toolstrips: The **Store** toolbar is for maintenance of pre-defined parameter sets for measurements (keys), the **Measurement** toolbar contains the functions necessary for execution of a single measurement.

In the **Parameter store** section, the keys available for the currently selected measurement type are visible and can be selected.

TOOLSTRIPS

Store



- creates a new parameter key item for the currently selected measurement type. Double click on the key name to rename it




- deletes the currently selected key



- drop down list for selection of measurement method for which a key should be defined / edited / deleted

Measurement



- drop down list for selection of measurement method for single measurement. Once a method has been selected, the name appears in the control



- sets the panel to parameter view



- shows the result of the last measurement



- starts measurement execution



- interrupts measurement execution



- drop down list giving access to options regarding measurement results

Save report – saves log of the measurement process and result to the selected folder and file

Save exception – if an exception has occurred, the report can be saved from here

Metrology → Templates

This control panel is used to manage existing template files, or create new ones.

TOOLSTRIPS

Main see *Chapter 1: Startup and General*, section *General Functions*

Action contains controls for template management




- creates a new image template. The currently selected template can be overwritten, or a new name can be entered. Specify the region within the current image that should be used as template (Aoi) and confirm. The new template is saved and appears in the template viewing section of the panel



- deletes the currently selected template

Test

- starts a test where the system tries to detect the selected template in the current image



- active image processor, can be changed by selection from the drop down list

Select


offers functions for browsing of the existing templates. The selected image template is shown in the viewing section of the panel, the name appears in the drop down list at the top



- jumps to the first template



- loads the previous template



- name of the currently selected template. From the drop down list, any other template can be selected



- loads the next template



- jumps to the last template

Exposure → Designs


The **Designs** control panel serves to manage the available designs on the design data source(s). On the left, a tree view shows the contents of the lic data source. The panel splits into a left and right part if properties view is selected.

TOOLSTRIP

Main see *Chapter 1: Startup and General*, section *General Functions*

DWL66SYSTEMCONTROLLER VIEW PANEL – FUNCTIONS

Several function buttons are available below the directory tree panel:

-  - updates the directory tree view
-  - adds a new main category folder
-  - adds a new subfolder to the currently selected category folder
-  - deletes the currently selected (sub)folder. A warning is issued if the folder or a subfolder in it contains design data
-  - deletes selected design
-  - splits the panel and shows the properties of the selected design in the right part

DWL66SYSTEMCONTROLLER VIEW PANEL – PROPERTIES

Misc → PossibleWriteModes

List of available write modes the design was prepared for

General →

Category

Name of the category/categories into which the design is sorted. First stands the root directory, sub-directories follow divided by points

Name

Design name

Provider

Lic source that provides the design

Data → Contains design information. Parameters are shown as set in the main line, and separately in the sub rows

Number of Stripes (not vector mode designs)

Number of stripes into which the design was divided

Path file (vector mode designs only)

Name of the conversion result file defining the exposure paths

Number of Elements (vector mode designs only)

Number of paths contained in the exposure

TypeName

denotes if a design contains data for scanning or vector mode exposure (BinaryData/GrayScaleData/VectorData)

ScanWidth (not vector mode designs)

Scan width selected during conversion. Can be extended to view number and unit separately

SizeOf Shows the design size. Parameters are shown as set in the main line, and separately in the sub rows

Unit Size unit

X/Y Sizes in the corresponding axes, in the given unit

Offset Shows where the lower left corner of the design will be positioned within the die. Parameters are shown as set in the main line, and separately in the sub rows

Unit Distance unit

X/Y Coordinate value in the corresponding axis, in the given unit

FocalLength

Focal length of the write head the design was prepared for. Parameters are shown as set in the main line, and separately in the sub rows

Unit Length unit (usually mm)

Value Focal length in the given unit

Scripts

In this panel, existing scripts for execution before or after a design or a job can be managed, and new scripts can be created. This can include scripts for alignment or operations that should regularly be done in combination with exposures, but are not part of the standard set of options (e.g., laser switch off after exposure). The script language is C#.

The **Script** control panel consists of toolstrips, a list of available scripts on the left, an info window with info on the currently selected script below, and the script editor on the right. For information on available functions, please consult Heidelberg Instruments.

Job

The job control panel is one of the central components of the system. It is divided into the browser section on the left and the editing/execution section on the right. The necessary general or specific functions are sorted into toolstrips.

The editing/execution section contains two function sets that can be selected by clicking on the related tab, if the related user permissions are given. The tabs show the name and some properties of the object that is currently being modified/executed. If in editing mode, the menu automatically swaps to the execution function set whenever a job is started, and swaps back afterwards. However, the results of the last job execution can still be viewed in the execution tab.

TOOLSTRIPS

Main see *Chapter 1: Startup and General*, section **General Functions**

Templates gives access to functions related to job templates

Requires user permission group Job.ModifyTemplates



- creates new template item according to the selection from the drop down list (MeasurementJob / MeasurementJobContainer / ExposureJob / ExposureJobContainer). Each template item appears in the related template subfolder.



- deletes the currently selected template. Deletion can also be done using the `Delete` key, or by right-click on the item and selecting **Delete**.

Job contains controls for the execution of exposure and measurement jobs



- starts execution of the currently highlighted job



- stops current job execution



- creates a new measurement job from the currently selected exposure job

Map contains general controls for setup of exposure and measurement jobs



- sets the currently selected die(s) to 'activated', meaning it will be executed during job execution



- sets the currently selected die(s) to 'deactivated'



-

opens a drop down list of all optional columns in the spreadsheet, sorted into groups. Click on a column name to change its state between visible and invisible. A tag indicates that a column is visible.



FullView

-

adjusts the size of the map representation to the available space between the parameter view / the toolbars and the panel border to make all fields visible with the largest possible size



/

-

clears the design(s) / measurement(s) from the currently selected die(s)

Tools

contains controls for setup of parameter series

Series ▾

-

opens a drop down list that contains parameters for which an exposure series can be created automatically over the currently selected dies. Once a parameter has been selected, a dialog window prompts the operator for start value and increment


Matrix

-

starts a process where two parameters can be selected for automatic creation of an exposure matrix within the selected map area. One parameter is varied along the row, one from row to row, creating all possible combinations of the parameter values given as range if all selected dies are connected. If the selected dies do not form a closed area, parameters still start at the leftmost / topmost die and change incrementally for each die from there, regardless of if it is selected or not

BROWSER SECTION

The explanations given here presume knowledge of the general explanations given in **Chapter 1: Startup and General**, section **General Functions**, subsection **Lists**.



The browser section contains all available jobs and, if related permissions are given (*Job.Modify*), a separate folder that contains all available job templates. Jobs can be stored either directly in the top layer, or sorted into job containers, if any were prepared.

Jobs or job templates can either contain exposures or measurements. There is no way to mix these types of action in the same job. In the same way, job containers can only contain jobs of one type.



- exposure job icon



- measurement job icon



- exposure job container



- measurement job container

Pull a template object down into the top level or any of the matching containers to create a job / job container. Containers may also be placed within containers.

EDITING/EXECUTION SECTION - EDITING CONTAINERS

Containers have certain properties they can hand down to all items that are sorted into this container, if these are set to inherit such properties. Other properties are related to the possibility of executing several jobs together as a batch job.

The properties of a selected container are shown in the **Editing** function set. They are:

Automation →

AutomationMode

determines menu behavior during loading/unloading. The options that can be selected from a drop down list are:

- **Manual** – loading and unloading are done fully manually
- **SemiAutomatic** – both loading and unloading process are supported by the menu
- **AutoUnload** – loading is done manually, but the stage automatically moves to the unload position after exposure

For more detailed information on the loading/unloading process with each of these options, refer to **User Guide I: Chapter 1**, section **Loading / Unloading Substrates**.

BeQuiet if set to True, warnings are suppressed. Useful e.g. for tests without focusing or with laser off.

Count down

allows to set a delay between start of the batch job and start of the first job e.g., to allow substrates to thermalize. The time can be entered either directly in the format d.h:m:s, or separately for each time unit by opening the parameter subset

ResetCoordinates

if set to True, the coordinate system is reset after the batch job has been completed

Laser (exposure job containers only) →**FinalMode**

determines setting of the laser power after the end of an exposure job. The options that can be selected from a drop down list are:

- **On** – the laser stays at the power last used for exposure
- **Off** – the laser is switched off
- **Idle** – the laser goes to a predefined idle laser power

Misc → LastDuration (view only)

shows the duration of the last processing of this job container as a batch job

Processing →**Exception reaction**

determines the behavior if an exception occurs during batch job processing. The options that can be selected from a drop down list are:

- **Proceed** – the menu logs the exception, but goes on with the processing
- **Request** – a dialog window opens informing about the fact that an exception has occurred and prompting the operator for the next action (proceed / stop / skip).
- **Stop** – the complete job is stopped with an error
- **Skip** – the rest of the current design/measurement is skipped, an error is written into the process report. The system resumes operation with the next design/measurement

Result →**AutoSaveResult**

if set to True, batch process results are automatically saved into the folder given in the parameter **ResultFolder**. These results only contain information shown also in the **Executing** function set after an exposure, no measurement results

ResultFolder

default storage folder for above option, other folders can be selected in the job properties

Scripts →**Before / After item**

scripts selected here will be executed at the beginning / the end of the batch job

Exception reaction

determines the behavior if an exception occurs during batch job script execution. The same options are available as for **Processing → Exception reaction**.

EDITING/EXECUTION SECTION - EDITING JOBS / JOB TEMPLATES

In principle, the **Editing** function set looks identical for jobs and templates. Therefore, if a template is edited, the background of the map turns to a different color (factory setting: coral), to warn the user that a template is being altered.

The set is divided into two sections, on the left a spreadsheet with the data for each field, and on the right a graphical representation of the map. Below the spreadsheet, additional parameter lists can be opened with the controls **Properties**, **Selection** and **Designs / Measurements**. The behavior of these sheets depends on several factors:

- if opened by just moving the pointer over the control, they close again immediately when the pointer leaves the region of the list
- if opened by a click on the control, a click outside the list is required to close it
- if pinned down with the red pin in the upper right corner of the list, the list turns into a fixed part of the **Job** panel and all other components are automatically arranged above it. In this state, the list only closes again after the pin is released and a click outside the area has happened



panel pinned down



panel released

Job Spreadsheet

The **Job Spreadsheet** contains one line for each field that was defined in the map setup (see **Properties**). Directly selected lines appear blue, lines selected via click in the map turn gray. Several successive lines can be selected by dragging the mouse pointer over them with the left button held down, or by selecting the first line and then holding down the **Shift** key while selecting the last one. Several non-consecutive lines can be selected by holding down the **Strg** key while selecting them one after the other. Lines selected in the spreadsheet also appear as selected in the map.

A right click on the map opens a context menu for operations that can be done on all selected lines at once:

- **Context menu**

Activate / Deactivate



Another way of changing the setting between activated for processing, or deactivated

Copy

Copies the contents of the currently selected line(s) into the clipboard

Paste

Pastes the contents of the clipboard into the selected line(s). If several lines were copied and just one line is selected, the lines below the selected lines will be overwritten as well

Clear ▶

Clears the contents of the selected column in the marked lines

Fill down ▶

Copies in the selected column the contents of the first cell down into the corresponding cells of all other marked lines

Displayed units Copies the contents of the currently selected line(s) into the clipboard

Which columns are available in a spreadsheet depends on the type of job (exposure/measurement). The first four/two columns of the spreadsheet are standard columns that are always visible whenever a new job is created. Others can be added via the related toolbar function (**Map** → **Columns**), so additional options can be viewed and set. A double click on a spreadsheet cell opens it for direct editing or for selection of an item, or opens an information field showing the full contents.

- **Standard columns:**

Die index

Active / inactive icon that shows if a field is set to be processed or not, and index of the related map field (die). A double field on the icon changes the active/inactive setting.

Designs / Measurements

Design to be exposed / measurement to be executed in this field of the map. Contents can only be altered via the **Selection** section, or via drag-and-drop of designs / measurements into the selected spreadsheet field(s) or the corresponding map field(s)

Intensity [%] (*exposure only*)

Light intensity to be used for the exposure. The necessary intensity depends on the write mode as well as thickness and sensitivity of the photoreactive layer and has to be found out by exposure series with varying intensity. Contents can be altered directly or in the **Selection** section

Focus [%] (*exposure only*)

Lens position offset with respect to the default focus position that should be used for the exposure. Which is the best focus position depends on resist thickness. Also, over longer times, drifts can lead to a change of the best focus position. Therefore, the focus has to be checked regularly in exposure series with varying focus. Contents can be altered directly or in the **Selection** section

• Optional columns:**Common → Before die script**

Activates a column where scripts can be selected that are executed before an exposure or measurement (e.g., a field alignment). Contents can be altered directly or in the **Selection** section

After die script

Activates a column where scripts can be selected that are executed after an exposure or measurement (e.g., a script to switch off the laser). Contents can be altered directly or in the **Selection** section

XY Offset (*exposure only*)

Shows the design offset in μm in the format (x/y). By default, the design origin is positioned at the center of the field. By entering an offset, the design can be shifted in X and Y direction. Positive numbers shift it to the right / up, negative numbers to the left / down. Keep in mind the orientation of the coordinate system. Contents can be altered directly or in the **Selection** section. Direct editing has to be done in the format x/y

Pen (*exposure only*)

If the field contains a vector mode design and the system has different pen configurations available in the current write mode, selection of the pen from a drop down list can be done here or in the **Selection** section

OS9 Command (*exposure only*)**NOTICE:****For maintenance only!**

Direct commands to the OS9 system controller can be entered here. This feature is only for maintenance and may only be used by experienced service personnel, as these commands can affect the system performance and even lead to damages.

Expodie → Expodie: AOD_Position (*exposure only*)
The AOD position determines the quality of the stripe connection (stitching) in y. If patterns show shifts in y at the connections, the AOD stepper position has to be adjusted to a new value. This value has then to be entered in all future exposure jobs

WriteHead → Z-Position (*exposure only*)

NOTICE: For maintenance only!

This parameter directly sets the write head position, disregarding the autofocus regulation. It can cause damage to the system, or lead to defocussed exposures.

Movement range is software limited to +/- 40 steps for safety reasons. However, damages are still possible depending on specific conditions.

AOD → ConstantCoefficient (fT0) (*exposure only*)

NOTICE: For maintenance only!

This parameter determines the start of the scan. Changing it will render the intensity correction invalid.

LinearCoefficient (dfT) (*exposure only*)

This parameter controls the scan width. If stripes don't connect properly horizontally (gaps or overlap), this parameter has to be adjusted. An increase closes gaps, a decrease removes overlap.

all other: (*exposure only*)

NOTICE: For maintenance only!

With the other AOD related parameters, the structure positioning within a scan can be influenced, which can lead to distorted exposures if not done properly.

Laserpower → Laserpower (*exposure only*)

Usually, this parameter does not have to be adjusted, as the control of the power on the substrate is done via the **Intensity** parameter, with the laser set at a value optimized for stability and longevity. However, under special conditions, it might be necessary to adjust the power e.g., for gray value exposures with low power, where the intensity correction might get too coarse if the power is set with the **Intensity** parameter. Depending on laser type and write mode, the laser power may be not adjustable. In this case, the column entry is ignored.

Map

The map section shows a graphical representation of the map layout defined in the **Properties** section. The background color shows if the map belongs to a normal job (standard background) or to a job template (user defined color, factory setting: coral). The background color setting for templates can be adjusted in the **Show options** list that can be opened from the **Main** toolbar (**Process item editor** → **TemplateColor**). The color can be edited in RGB format, or selected from three different palettes (Custom, Web, System) that are accessible via drop-down list.

Some graphical features give information about map and field parameters:



- The upper left edge shows by icon and color if the field is activated for processing (green, tag) or not (red, cross). A double click on the icon changes the state.



- The color of a field shows if it has been selected (dark) or not (light). Selection can be done in the spreadsheet or the map. Selection of a region of fields in the map can be done by dragging the mouse pointer over them with left button pressed, or by clicking on one of the corner fields and then holding down the **Shift** key while clicking on the opposite corner. Selection of several fields that are not connected can be done by holding down the **Ctrl** key while clicking on them.



- A cross in light gray shows the location of the map origin as selected in the **Properties** section. It can be in the center of a field or on any of the edges or corners (see below).



- to the right of the active/deactivated icon, an icon shows information about the field contents. A filled vector structure stands for a design (exposure job), a stylized oscilloscope for a measurement.



- the same icon also shows if the field contains just one design/measurement, or several (example for designs).

Note: Icons are only visible if the map field is large enough.

Like the spreadsheet, the map offers a context menu that allows to make operations on selected fields. The context menu is in general identical to that of the spreadsheet, but there is one item:

Show list entry Moves the spreadsheet so that the line related to the map field on which the context menu was called is visible

Properties

This parameter set is related to the selected item (exposure job / measurement job) as a whole. Most of the listed parameters are identical to the ones for containers. In such cases, an additional option *inherited* is available, which means that the container setting is used.

Automation →

AutomationMode

determines menu behavior during loading/unloading. The options that can be selected from a drop down list are:

- **Manual** – loading and unloading are done fully manually
- **SemiAutomatic** – both loading and unloading process are supported by the menu
- **AutoUnload** – loading is done manually, but the stage automatically moves to the unload position after exposure
- **Inherited (...)** – uses the selection of the container (current selection shown in brackets)

For more detailed information on the loading/unloading process with each of these options, refer to **User Guide I: Chapter 1**, section **Loading / Unloading Substrates**.

BeQuiet if set to True, warnings are suppressed. Useful e.g. for tests without focusing or with laser off.

Count down

allows to set a delay between start of the job and start of the exposure e.g., to allow a substrate to thermalize on the stage. The time can be entered either directly in the format d.h:m:s, or seperately for each time unit by opening the parameter subset

ResetCoordinates

if set to True, the coordinate system is reset after the job has been completed

Misc → LastDuration (*view only*)

shows the duration of the last processing of this job

Dimension →**Column count**

number of columns in the job layout

Row count

number of rows in the job layout

Size of die

size of each field in the job layout

Exposure / Measurement →**Exception reaction**

determines the behavior if an exception occurs during job processing. The options that can be selected from a drop down list are:

- **Proceed** – the menu logs the exception, but goes on with the processing
- **Request** – a dialog window opens informing about the fact that an exception has occurred and prompting the operator for the next action (proceed / stop / skip).
- **Stop** – the complete job is stopped with an error
- **Skip** – the rest of the current design/measurement is skipped, an error is written into the process report. The system resumes operation with the next design/measurement

Field Zero →


Indices sets the location of the origin within the job layout by denoting column (X=) and row (Y=) of the field in which it should be located. Parameters are shown as set in the main line, and separately in the sub rows. They can be modified manually in both places

X column index of the field containing the origin


Y row index of the field containing the origin

Location determines where within the field the origin is located. The options that can be selected from a drop down list are:


• **top left**




• **top center**



• **top right**




• **center left**




• **center**




• **center right**




• **bottom left**



• **bottom center**



• **bottom right**



Focussing (exposure jobs only) →

Mode offers a drop down list with focusing modes available on the system for selection

Laser (exposure jobs only) →**FinalMode**

determines setting of the laser power after the end of an exposure job. The options that can be selected from a drop down list are:

- **On** – the laser stays at the power last used for exposure
- **Off** – the laser is switched off
- **Idle** – the laser goes to a predefined idle laser power

Report (measurement jobs only) →**ReportFolder**

folder into which the measurement results should be stored

ReportName

mask for naming of reports. Available components are

- **<Name>** – job name
- **<Date>** – date of process execution
- **<Time>** – finish time of process execution

These components can be arranged in any order, and any other characters may be used in between, within the limits set by the operating system

ViewReport

if set to True, the measurement report is opened for viewing after process execution

Result →**AutoSaveResult**

if set to True, process results are automatically saved into the folder given in the parameter **ResultFolder**. These results only contain information shown also in the **Executing** function set after an exposure, no measurement results.

If set to Inherited (...), the selection of the container is used (current selection shown in brackets)

ResultFolder

storage folder for above option.

Scripts →**Before / After every die**

scripts selected here will be executed at the beginning / the end of every die within the job

Before / After item

scripts selected here will be executed at the beginning / the end of the job

Exception reaction

determines the behavior if an exception occurs during script processing. The same options are available as for **Processing** → **Exception reaction**.

Selection

This list has several sections. On the left, it shows the properties of the selected dies in a table. If several dies have been selected, only property values that are identical are shown. All other value fields are left blank.

The right half is dedicated to displaying information about the design(s) used in the die(s).

Die properties are:

Design →

Offset shows the design offset in μm in the format (x/y). By default, the design origin is positioned at the center of the field. By entering an offset, the design can be shifted in X and Y direction. Positive numbers shift it to the right / up, negative numbers to the left / down. Keep in mind the orientation of the coordinate system. Can also be altered directly in the spreadsheet if the column has been set to visible.

Parameters are shown as set in the main line, and separately in the sub rows. They can be modified manually in both places

X / Y offset values in the given units

Unit length unit used for the offset. Has no effect on the representation in the spreadsheet. Units in the spreadsheet have to be altered via the context menu

Focussing →

Offset lens position offset with respect to the default focus position that should be used for the exposure. Which is the best focus position depends on resist thickness. Also, over longer times, drifts can lead to a change of the best focus position. Therefore, the focus has to be checked regularly in exposure series with varying focus. Can also be altered directly in the spreadsheet

General →

Count down

allows to set a delay before processing of the selection starts. The time can be entered either directly in the format d.h:m:s, or seperately for each time unit by opening the parameter subset

Activated if set to True, the die will be processed during execution. Can also be set in the spreadsheet (die index column) or the map

Laser →

Intensity light intensity to be used for the exposure. The necessary intensity depends on the write mode as well as thickness and sensitivity of the photoreactive layer and has to be found out by exposure series with varying intensity. Can also be altered directly in the spread sheet

Power Usually, this parameter does not have to be adjusted, as the control of the power on the substrate is done via the **Intensity** parameter, with the laser set at a value optimized for stability and longevity. However, under special conditions, it might be necessary to adjust the power e.g., for gray value exposures with low power, where the intensity correction might get too coarse if the power is set with the **Intensity** parameter. Can also be altered directly in the spread sheet if the column has been set to visible.

Parameters are shown as set in the main line, and separately in the sub rows. They can be modified manually in both places

Power laser power in the given unit

Unit unit used for laser power in the **Selection** sheet. Has no effect on the representation in the spreadsheet. Units in the spreadsheet have to be altered via the context menu

If no value is set, the default value defined in the laser setup is used.

Misc → LastDuration (view only)

shows the duration of the last processing of the selection

Scripts →**Before / After die**

Scripts selected here will be executed at the beginning / the end of every die in the selection.

Before / AfterEveryDieScript

This field serves to show scripts that were already defined in the **Properties** section for all dies of the map.

The design information section consists of a list of all designs used in the active selection on the left, and a text box for data lists on the right. In addition, there are some controls for modifications of view and design parameters:

Remove – updates the directory tree view

Apply for all – copies the design to all selected fields

Clear – clears the design list, deleting all design entries of the selection

Design – changes the data in the text box to the parameters decided during conversion (read only)

Parameters – changes the data in the text box to the parameters decided by menu settings

The menu editable parameter list shows the following parameters:

Misc → DebugFlag

sets the level of system side debugging during exposure of the selected design if menu is in debug mode:

\$0800 program variables

\$0400 Parser

\$0100 Messages

\$0004 calculated values

If not told another value by a Heidelberg Instruments engineer, use \$900 for collection of debug information.

Exposure count

number of times each exposure of the design within the selection is repeated

Focus mode

offers a choice between available focus modes, or to inherit this choice from the map properties (Inherited, default setting). Available choices depend on system hardware configuration

Write mode

offers a choice between available write modes, considering the way conversion was done (vector mode conversion → only vector mode write modes allowed etc.)

Designs

This parameter set shows the available designs and contains tools to manage them or get more information about a design. From here, designs can be added to the job by drag-and-drop into a spread sheet line or a map field. If a selection is active in the spreadsheet/map and the design is dragged into any field for this selection, it is added to all fields of the selection.

Note: This panel can also be accessed separately via Controls → Exposures → Designs.

The design list is a standard folder list. The available controls are:

update – re-reads the list of available designs from the design source



– adds a new folder in the top layer. User is prompted for a folder name



– adds a new subfolder in the currently selected folder. User is prompted for a folder name



– deletes the currently selected folder



– deletes the currently selected design

Properties - opens/closes the **Properties** section in the right part of the **Designs** parameter set, where properties of a currently selected design are shown

System Control

The system control panel is the central control panel for direct hardware control on an operator level. It is useful for the more advanced operator to have more flexibility in job execution, or for tool debugging.

The panel is divided into a functions section on the left, where predefined function sets can be shown or hidden, and a parameter section on the right. The number and contents of the toolstrips available in this panel are very flexible. A wide selection of possible toolstrip parameters is offered in the **Show options** toolset. Therefore, available toolbar functions are described in their context here instead of the location. Also, the handling of the toolstrip adjustment section of the **Show options** toolset is described.


STAGE FUNCTION SET

NOTICE:

The machine can be damaged irreversibly if stage movement leads to a crash of the write head nozzle against the substrate or another obstacle.

Therefore, the controls have to be used with caution, and it has to be made sure that no such collisions can happen.

- If a substrate should be measured, make sure that its surface is not tilted
- Make sure focusing was done well on the substrate, not close to the edge or beside the substrate



This set of functions also appears partly or fully in several other panels and wizards. It contains all necessary controls for manual stage movement:

Step size controls – These controls determine the step sizes for movement with the movement controls.

With the **slider**, adjustment of the step size to arbitrary values is possible. The currently selected value is visible in the **status line**.

The **buttons** set the step size to the discrete value given on it. The slider is adjusted automatically.

The **list arrow** to the left of the center button between the arrows opens a panel that allows to change the step values on the buttons.

Movement controls – These controls immediately start stage movements.

With the four **arrow buttons**, stepwise movements by the pre-selected increments are done. Each click starts a movement in the direction indicated by the arrow by one step.

The **button in the center** activates a Point of Interest measurement in the **HIVision** program. The point selected here is then moved to the center of the image field.

With the **Load** button, a loading / unloading movement sequence is started. The write head moves up, and the stage moves to the pre-defined **Load** position. This movement is done in the interferometer coordinate system. The choice of origin in the job coordinate system has no influence.

The **Center** button moves the center of the movement range below the write head.

Origin control – The **Set zero** control resets the job coordinate system to 0,0 in the current position.

 /  – collapses / expands the **Stage** function set

WRITEHEAD FUNCTION SET

This function set gives manual control over the position of the write lens.



Focus-Offset –

This slider allows to fine adjust the position of the lens after focusing, to optimize the camera image or adjust the position of the focal point to compensate e.g., for resist thickness. The current value is shown above the slider. Controls at both ends of the slider allow to jump directly to the limit values. A control to the right of the status text allows to reset the slider to **0**.

 – **Focus**; moves down the write head until the standard focus position has been reached

 – **Standby**; moves the write head up into a standby position without resetting the counter

 /  – collapses / expands the **Writehead** function set

SHOW OPTIONS

 The **Show options** function is part of the **Main** toolbar of every panel. A click on it opens the **Edit wizard settings** panel. This panel consists of two parts, the list of **general options** on the left, and the **Toolbar manager** on the right.

 – Saves the settings and closes the panel

 – Closes the panel without saving

The available general options depend strongly on the panel. It can be color settings, units for movement or measurement, or the list may even be empty.

The toolbar manager consists of two segments, the two top toolbars and a section showing the current status of the edited toolbar.

Toolstrips

 – creates a new toolbar

 – deletes the currently selected toolbar

<selected item> – opens a drop-down list of the currently available toolstrips. The selected toolstrip can then be edited with the tools in the **Items** toolstrip. The control shows the name of the currently selected toolstrip

Items

Commands – Opens a drop-down list that contains all commands available as toolstrip items

Measurement – Opens a drop-down list that contains all measurement algorithms available as toolstrip items. For descriptions of the measurement methods, refer to the section on measurement recipes in **Chapter 3: Controls**

Script – Opens an editor that allows to create a toolstrip item linked to a script

Separator – Adds a separator behind the last item in the toolstrip

 – deletes the currently selected item

TOOLSTRIP ITEMS – COMMANDS

This is a list of available toolstrip functions as they are sorted in the **Show options** toolset. The real sorting into toolstrips that is found in the **System control panel** might be completely different. Availability of some controls depends on system configuration.

Interferometer **Reset** – resets the interferometer

Update – re-reads the current position

Selected write head

 – **Initialize;** moves the write head into the upper end position and resets the counter

 – **Freeze;** keeps the write head lens in the current position, disabling the autofocus regulation

 – **Fix;** fixes the write head lens in a position, disabling the autofocus regulation. Fix position is determined by the entry in the text box that is accessed by clicking on the arrow

 – **Enable;** re-activates the autofocus regulation after Fix or Freeze has been used

 – **Focus;** moves down the write head until the standard focus position has been reached

 – **Standby;** moves the write head up into a standby position without resetting the counter

Shutter, Laser



Eye damage!

The DWL 66⁺ uses a laser of either laser class 4 or 3B (according to DIN EN 60825:1) that is under misuse potentially harmful to the eye.

- Don't stare into the beam
- Don't put anything reflective into the beam path



– opens the laser shutter, allowing the beam to travel through the optical setup



– closes the laser shutter, blocking the beam



– switches the laser on



– switches the laser off

Stage (Coordinates)

Reset coordinates –

resets the job coordinate system to the interferometer coordinate system (raw coordinate system)



– **Initialize;** moves to the home position and resets the interferometer coordinate system



– **Shift position;** moves the origin of the job coordinate system by the distances given in the following dialog window



– **Set position;** a dialog window opens requesting the coordinates that should be assigned to the current position in the job coordinate system



– **Set 0,0;** sets the current position as origin for the job coordinate system



– **Rotate coordinates relatively;** rotates the job coordinate system by a given increment.



– **Set absolute coordinate rotation;** rotates the job coordinate system to the given angle relative to the interferometer coordinate system

Stage (Movement and Positions)

NOTICE:

The machine can be damaged irreversibly if the stage is moved using one of the controls listed here while the write head is not in retracted position.

Always move the write head into **Standby** position before starting a movement with these controls, or make sure it cannot hit any object loaded on the stage.



– **Move**; the stage moves by the increments given in the following dialog window. Direction is decided by signs.



– **Move to coordinates**; the stage moves to the job coordinates given in the dialog window that follows

Raw move to –

The stage moves to the interferometer (raw) coordinates given in the dialog window that follows

Edit...

– **Edit positions**; opens a panel where coordinate sets can be stored under a name describing the position

MoveTo ▾

– **Move to position**; opens a drop down list of positions that were defined using the **Edit positions** function. A click on one of the positions starts a stage movement towards that position.

Axes ▾

– Axes control; gives direct control over the motors. The motors can be disabled or enabled axis-wise, or simultaneously with the commands in the drop-down list

LithographySystem – Camera Tools



– **Center camera position**; moves a **Point of Interest** selected in the camera image to the center of the image

LithographySystem – Positions

NOTICE:

The machine can be damaged irreversibly if stage movement leads to a crash of the write head nozzle against the substrate or another obstacle.

Therefore, the controls have to be used with caution, and it has to be made sure that no such collisions can happen.

- If a substrate should be measured, make sure that its surface is not tilted
- Make sure focusing was done well on the substrate, not close to the edge or beside the substrate

The positions cited here have factory default settings matching the names. However, these can be edited with the Edit positions function (item list **Stage** → **Edit...**) .

Load	moves the stage to the Load position
Unload	moves the stage to the Unload position (usually identical with Load)
Center	moves the stage Center below the write head
Exchange	moves the stage to the position for writehead Exchange

Chapter 4: Wizardry

The wizards are the most basic tools of the **Lithography Menu**. They lead through standard procedures, using standard parameters in many steps. The wizards are sorted into thematic submenus:

Writehead

↳ Calibrate beam offset

Leads through the steps of a beam offset measurement on a two layer overlay exposure. Required for overlay exposure calibration.

Requires user permission group Wizard.Access.BeamOffsetCalibrationWizard or Controls.Access.AllWizards

Camera

↳ Calibrate camera offset

Opens a wizard for measurement of the distances between the cameras of the systems by measurement of a reference structure

Requires user permission group Wizard.Access.CameraOffsetcalibrationWizard or Controls.Access.AllWizards

↳ Calibrate BSA camera offset

Opens a wizard for measurement of the distances between the cameras of the systems according to exposures

Requires user permission group Wizard.Access.BacksideCameraOffsetCalibrationWizard or Controls.Access.AllWizards

↳ Calibrate camera

Leads through a measurement that returns the distances in X and Y on a substrate that correspond to one pixel step in the camera.

Requires user permission group WizardAccess.CameraCalibrationWizard or Controls.Access.AllWizards

Alignment

↳ Global alignment

Leads through the steps of a two point alignment that allows to calculate the angle of a substrate, and rotate the user coordinate system accordingly.

Requires user permission group Control.Access.GlobalAlignmentWizard or Controls.Access.AllWizards

↳ Create alignment script

Serves to set up a custom alignment script. Scripts can be defined either for global alignment at the very beginning of a job, or for field alignment to separate dies. Several field alignments can be used in the same job.

Requires user permission group Wizard.Access.AlignmentScriptCreationWizard or Controls.Access.AllWizards

Job management**↳ Create/execute exposure job**

Requests all information required for exposure of a single design in the center of a substrate.

Requires user permission group Control.Access.ExposureItemWizard or Control.Access.AllSequentialWizards

The wizards are explained to their full extent in the related step-by-step instructions in **User Guide I: System Operation**.

Chapter 5: Tools

The **Tools** menu comprises mainly of functions and panels that influence the setup and usage of the menu.

Floating Container –

This control governs the visibility of the **Floating Container** for external placement of panels

Change Password –

A function that allows a user to change his own password. Follow the instructions given in the dialog window

User manager – Control panel for setup and administration of menu users. See the section **User Permissions Management** in **Chapter 1: Startup and General** for more information.

Requires user permission group Database.Administration

Log Service – Opens a sub menu for logging control

Start – starts debug logging according to the settings done in the panels of the **Devices** menu

Stop – stops logging

Compress – compresses the log files ...

DebugLevel – if higher debug levels have been set via panels of the Devices section, they can be reset to standard level here ...

LiveWindow – re-opens the **LiveWindow** showing online debugging information if it was closed before

Requires user permission group Menu.AccessLogService

FireFips – Gives access to options regarding control of the HIVision program

Start – restarts the HIVision program if it was accidentally stopped, or crashed

Stop – stops the HIVision program. Might be necessary for debugging or troubleshooting

Edit configuration –

shows the HIVision program configuration. See below for more details

Show communication –

shows the communication between menu and HIvision program. Might be necessary for debugging or troubleshooting

Requires user permission group Menu.AccessFireFips

Configuration – Gives access to several system configuration tools and options**Create summary –**

puts together the system configuration data to save it into an xml file. This file can be helpful for system analysis and trouble shooting

Requires user permission group Menu.AccessConfiguration

Edit menu configuration –

opens the configuration panel for all menu settings. Further description below

Requires user permission group Menu.AccessConfiguration

Set as default –

saves the current setup as default for the selected user group

Requires user permission group Menu.AccessConfiguration

Reset to default –

reloads the last setup that was defined as default for that group for the specific user selected

Requires user permission group Menu.AccessConfiguration

Transfer – transfers the setup for the current user to a different user, excluding any settings that collide with the permissions given

Requires user permission group Menu.AccessConfiguration

SaveAll – saves all current settings, defined modes etc.

Requires user permission group Menu.AccessConfiguration

DebugLevelEditor –

Opens an editor where debug levels can be selected separately for the system components to generate debug logs for trouble shooting

FireFips Configuration

File system

↳ **CommandDefinitionFile**

name of the file that defines the command set available to the menu for communication with HIVision

↳ **FilenameOfExecutable**

name and location of the HIVision executable file

↳ **TemplateDirectory**

directory used by HIVision for temporary storage of templates

↳ **WorkingDirectory**

working directory of the HIVision program

GUI Bounds (read only)

↳ Contains all parameters on size and position

↳ **GUI_Status**

denotes the status of the HIVision GUI (0 – not started, 1 – running)

TCP/IP

↳ **IPAddress**

IP address of the HIVision server

↳ **Port**

communication port for communication of the menu with the HIVision server

↳ **Timeout**

Timeout for wait for replies after sending comments

Menu configuration

EDIT MENU CONFIGURATION PANEL

Logging

↳ **CommonLogPath**

Path where log files are saved

↳ **LimitLiveWindowLines**

Enables (True) or disables (False) a limitation of the number of lines available in the **Live Window**

↳ **MaximalLiveWindowLines**

Number of lines to which the **Live Window** is limited if the related option is activated

↳ **ShowLiveWindowAtStartup**

Determines if the **Live Window** is started during menu startup. If set to 'False', the Live Window can still be started from **Tools → LogService → LifeWindow → Start**

SystemConfiguration

↳ **HIMT_PG**

Opens the **Edit system menu configuration** panel (see below)

EDIT SYSTEM MENU CONFIGURATION PANEL

Logging

Name and path of the currently used log

UserConfigurations

Here, the default units used in the menu can be set for each user

Warnings

Warnings for optional parameters at job start can be activated (true) or deactivated (false) for each optional parameter available

DebugLevelEditor

In this editor, all devices are listed with their available debug levels in a drop down list. Open the drop down list beside the device that should be debugged and select the required debug level.



– Saves the settings and closes the panel



– Closes the panel without saving

Standard –

resets all devices to standard debug level

Detailed –

sets all devices to detailed debug level

Chapter 6: Devices

Which devices are listed in this menu depends on the system configuration. The only common device panel, the **Cameras** panel, is fully described in the related sections of *User Guide I: System Operation*.

For each hardware component or component group, a separate panel is available to adjust settings or parameters or do trouble shooting. While each panel has some features related to the specific component, some controls are similar for all.

Common Toolbars

PROPERTIES

This toolbar is part of any device panel.



Update View. Allows to update the shown parameters.



Setup view. In some device panels, a selection is possible between the display of common and specific controls. Availability of such a control set can be seen from the small arrow at the side of the icon. If **Specific** is selected, only this control set is displayed in the standard view. If it is deselected, only the common control set is displayed, regardless of the arrangement of control sets selected.

Requires user permission group Device.AccessSpecificArea



Split view splits the data part of the device panel into sections with one panel in each.



Tabbed view puts every panel into a separate tab



Activate / deactivate dummy mode. If dummy mode is active, a blue frame appears around the icon

Requires user permission group Device.AccessDummyMode



Edit device configuration. Opens the device configuration panel for editing. Contents of the panel depend on the device

Requires user permission group Device.AccessConfiguration



Initialize device. Confirm to start an initialization sequence. No communication with the device is possible during initialization

Requires user permission group Device.Initialize



Show device information. Opens a table with some general device information



Show last initialization exception. Only visible if an exception has occurred. Opens the exception information window for the last exception that occurred during initialization of this device.

LOG

This toolbar appears in panels of devices that are not directly controlled by User PC, but require communication of the menu with either another controller, or the component itself.

Requires user permission group Device.AccessLog



Opens / closes the communication log panel. A blue frame around the icon appears if the log is open, and the next control gets active



Log panel button with function selection between **Save** and **Clear**. Save saves the current log contents to a file (select path and name in the dialog), while **Clear** deletes all current entries. Select one to give the button the related function

CONNECT

Like the **Log** toolbar, this toolbar appears in panels of devices that are not directly controlled by User PC, but require communication of the menu with either another controller, or the component itself. This communication requires ports that can be activated or deactivated, which might include login/logout procedures.



Connect to controller / device



Disconnect from controller / device

Communication log section

Apart from the cited common toolbars, the device panel usually contains specific toolbars with contents depending on the device. Also, the contents of the standard main section are device dependent, it might contain parameter sets, additional control functions or a log. However, the communication log section that opens when activated from the communication toolbar has a common setup.

TABS

A register card appears for every communication channel relevant for the device. This can e.g. be the communication with the OS9 system controller, or with the board itself. The tab shows which communication channel a register card monitors.


FUNCTIONS

Several functions for content control are contained in each register card. These are:

Save button Saves the current contents of the log section in the currently active register card into a log file

Clear button Clears the log section of the currently active register card

Autoscroll checkbox If activated, the log text scrolls so that the last line always stays visible. Otherwise, the scroll slides have to be used to reach the end of the log.



Appendix A: Glossary

Job coordinate system

(also: **user** coordinate system)

This term denotes a temporary coordinate system that can be adjusted to the requirements of each job. After stage initialization, the origin of the job coordinate system is located in the center of the stage, and rotation with respect to the interferometer coordinate system (see below) is zero. Via manual choices or alignment sequences, the job coordinate system can be e.g., adjusted to the center of the substrate, or optical alignment marks.

Interferometer coordinate system

(also: **raw** or **absolute** coordinate system)

This is the basic coordinate system based on the optical setup of the interferometer system that measures the stage position. The origin for each axis is located at the related interferometer receiver beam in/output window.

Die

(also: **field**)

Originally, the term **die** or **dice** comes from the cutting of a wafer (**dicing**) into small units, each of which is the basis of a chip. In the present documentation, the term is used synonymously for the area on a wafer or plate that is covered by just one design. This corresponds to one field of the map grid defined to divide up the available area into sections that contain one design.

Overlay

In the present documentation, the term **Overlay** denotes the exposure of several design layers on top of each other with an optical measurement in between to determine the current position of the previous layer(s). The precision of a second exposure that is done directly after the first one without such a measurement is referred to by the term **Registration**.

Gray scale exposure

The gray scale exposure mode is an option that allows 3D structuring of resists to form e.g., molds for micro-optical components, in a single exposure. In this mode, 100% corresponds to an energy that exposes the resist just down to the required depth. 126 equidistant energy values are defined in between 100% and 0, each of which reaches less deep into the resist.

The resulting depth of each step within the resist depends on the resist response. Therefore, for 3D structuring, resists with linear response are most useful. No undercuts are possible with this method.

Gray scale exposure settings are determined during design conversion. Refer to the **Conversion Software Manual** for more information. Only designs defined in DXF, STL, BMP or X,Y,Z-ASCII format can be converted. For exposure of designs converted for gray scale mode, the correct write mode is selected automatically.

Vector mode

With vector write mode, designs that consist only of a few narrow lines but cover a large area (like e.g., waveguides or micro-fluidic channels) can be exposed in a more effective way. In standard write mode, the whole area within which structures exist is scanned, and the laser beam is turned off and on with the required energy wherever there is a design part. In this way, lines are created by many exposure flashes.

In vector mode, a line is written in one stroke, where the laser beam is switched on at the beginning, and off at the end of the line, and the stage moves in between according to the line direction(s). This improves line quality a bit, but mainly, it can save time if in the usual way a lot of empty areas would have to be scanned. Vector mode can only be used for designs created in Gerber format.

Appendix B: Revision History

This section contains additions, changes and bug fixes issued after the version this manual is based on.

Version	Build	Affected Menu Section	Change
1.2	5130.25280	-	-

Notes

Notes

Notes