

## Simulated Annealing

- At high temperature can move around
  - not trapped to only make "improving" moves
  - free energy from "temperature" allows exploration of non-minimum states
  - avoid being trapped in local minima
- As temperature lowers
  - less energy available to take big, non-minimizing moves

5

- more local / greedy moves

```
Penn ESE535 Spring 2009 -- DeHon
```


## **Design Optimization**


### Components:

- 1. "Energy" (Cost) function to minimize
- represent entire state, drives system forward
- 2. Moves
  - local rearrangement/transformation of solution
- 3. Cooling schedule
  - initial temperature
  - temperature steps (sequence)
  - time at each temperature

#### enn ESE535 Spring 2009 -- DeHon

6





8

γ


0.5


0.95


0.8


10

Details VPR Cooling Schedule Cooling schedule - fixed ratio:  $T=\lambda T$  Moves at Temperature = cN<sup>4/3</sup> • (e.g. λ=0.85) Temperature Update - temperature dependent - Tnew=Told×γ - function of both temperature and α acceptance rate - Idea: advance slowly · example to come in good  $\alpha$  range α > 0.96 Time at each temperature  $\Box \alpha$  is measured 0.8 < α ≤ 0.96 0.9 acceptance rate - fixed number of moves? 0.15 < α ≤ 0.8 Betz, Rose, & Marquardt - fixed number of rejected moves? α ≤ 0.15 Kluwer 1999 - fixed fraction of rejected moves? ESE535 Spring 2 ESE535 Spring 2009 -- DeHon
















Criticality Exponent	Placement Estimated Critical Path (ns) (20 Circuit Geometric Average)	Wiring Cost (20 Circuit Geometric Average)
1	38.9	342.0
2	37.1	343.4
3	35.9	344.0
4	34.8	344.7
5	34.7	343.7
6	34.8	341.6
7	34.3	339.6
8	34.3	340.1
9	33.8	339.6
10	34.3	337.9
11	34.3	336.3


























# Range Limit

- Want to tune so accepting 44% of the moves – Lam and Delosme DAC 1988
- VPR
  - Define Rlimit defines maximum  $\Delta x$  and  $\Delta y$  accepted
  - Tune Rlimit to maintain acceptance rate

26

- Rlimit<sup>new</sup>=Rlimit<sup>old</sup>×(1-0.44+ $\alpha$ )
  - $\Box \alpha$  is measured acceptance rate

nn ESE535 Spring 2009 -- DeHon



**Big Hammer** 

- (part, placement, route, retime, schedule...) Can have hybrid/mixed cost functions

- resignation to finding/understanding structure

29

- as long as weight to single potential

· Costly, but general


- place and route


nn ESE535 Spring 2009 -- DeHon

Works for most all problems

– (e.g. wire/time from VPR)
With care, can attack multiple levels

· Ignores structure of problem





### 5

## Admin

• Reading for Monday online

n ESE535 Spring 2009 -- DeHon

## Big Ideas:

- Use randomness to explore large (nonconvex) space
  - Sample various parts of space
  - Avoid becoming trapped in local minimum

32

- Technique
  - Simulated Annealing

Penn ESE535 Spring 2009 -- DeHon

31